

Cements

Permanent- Panavia

Temporary- Sterioss Improv

Retrieval- #1 being the least retentive/Jon M. Finley, DDS

1. Neugnot
2. Temp Bond w/Vaseline
3. Straight Temp Bond
4. ZOE W/Temp Bond

Occlusal Plugs

Floss technique-

1. Place floss in abutment opening prior to cementation of crown.
2. Cement crown onto abutment.
3. Place a small twist drill into occlusal access hole of the crown picking up floss in the abutment. Slowly remove floss, cleaning out any cement that has filled the hole.
4. Place new floss and plug with choice of composite.

Note: This procedure can also be done on the model. For an outline of this technique request Article 3 from either Calcitek or Ragle Dental Lab. Other techniques can be used if so desired.

Light cured material-

Fermit by Vident is a light cured material specifically made for this purpose. Vident/800-828-3839