

Bar/Clinical**#1 IF ENOUGH VERTICAL:**

- 1) Remove healing cuffs.
- 2) Place 5mm inserts w/Hex drive.
- 3) Place transfer coping onto inserts.
- 4) Relieve inside of denture to except transfer heads.
Note: Inserts are available in 2,3,4, & 5mm heights
- 5) Take impression with denture in place.
- 6) Remove transfer copings and inserts.
- 7) Replace healing cuffs.
- 8) Send impression along with transfer kit to lab.

#2 NOT ENOUGH VERTICAL**OPTION #1** (*Rebase*)

- 1) Remove healing cuffs.
- 2) Place 5mm inserts w/Hex drive.
- 3) Place transfer coping onto inserts.
- 4) Take impression
- 5) Remove transfer copings and inserts.
- 6) Replace healing cuffs.
- 7) Send impression along with transfer kit to lab.

OPTION #2 (*Reline*)

- 1) See option #1 steps 1-7.
- 2) Pour model with analogs.
- 3) Make bar.
- 4) Return for try-in.
- 5) Relieve denture
- 6) Make access holes for extended screws.
- 7) Take reline impression over bar and screws.
- 8) Remove long screws.
- 9) Remove denture with bar in place.
- 10) Send to lab for processing.